



1.750"

TYPICAL RAIL ASSEMBLIES


INSTALLATION TIPS:

- 1. ALWAYS USE ALL THE SCREW HOLES PROVIDED TO ATTACH THE RAILING SYSTEM.
- 2. SOLID BLOCKING IS REQUIRED AT ALL WALL ATTACHMENT POINTS
- 3. ON LONG RUNS OF RAILING, BRACING IS REQUIRED AT MEETING SECTIONS.

JOB TITLE DRAWING TITLE STEEL RAIL SYSTEMS DRAWN BY SCALE CSD NTS 02/27/19 APPROVED MATERIAL/FINISH DRAWING TITLE STEEL RAIL SYSTEMS DATE APPROVED

LORENZO METALWORKS


LARRY BRAVERMAN- 1585 BEACH LAKE HIGHWAY, BEACH LAKE, PA 18405 PH: (570) 470-2920 e-mail: LB@lorenzometalworks.com



ELEVATIONS: RAIL SYSTEM

ATTAINING LENGTH MEASUREMENT:

- 1. DETERMINE SMALLEST DISTANCE BETWEEN WALLS WHERE THE RAILING WILL FIT. DO THIS BY USING A LEVEL TO DETERMINE IF THE WALLS ARE PLUMB AND FLAT
- 2. MARK ON THE FLOOR, THE POINT ON EACH WALL WHERE THE LEVEL READS PLUMB. THIS IS THE SMALLEST MEASUREMENT.
- 3. MEASURE BETWEEN THESE TWO POINTS. SUBTRACT 1/16" FOR CLEARANCE. THIS IS THE OVERALL LENGTH OF THE RAIL SYSTEM.



JOB TITLE DRAWING TITLE STEEL RAIL SYSTEMS DRAWN BY SCALE CSD NTS 02/27/19 ITEM CODE MATERIAL/ FINISH DRAWING TITLE STEEL RAIL SYSTEMS DATE APPROVED

LORENZO METALWORKS

LARRY BRAVERMAN- 1585 BEACH LAKE HIGHWAY, BEACH LAKE, PA 18405 PH: (570) 470-2920 e-mail: LB@lorenzometalworks.com